




# Spare parts

Spare parts for truck mixers

# Intermix truck mixers

## We offer you:

- Spare parts for all makes of truck mixers
- Customer service and repairs
- Spare drums with installation on request

## Options for spare drums:


- Primed or with individual varnishing
- With additional end helix sheets
- Helix sets
- Size from 6 m<sup>3</sup> to 16 m<sup>3</sup>

We are happy to prepare an offer for you!




# Spare parts for truck mixers

## Load-bearing roller



| Load-bearing roller | Article no. |
|---------------------|-------------|
| 6 m <sup>3</sup> LH | 1-17-001    |
| 9 m <sup>3</sup> LH | 5-17-001    |



| Load-bearing roller    | Article no. |
|------------------------|-------------|
| IMI 6-8C               | 6-17-001    |
| IMI 8-12               | 9-17-001    |
| ST 8-10 m <sup>3</sup> | 9-17-150    |




| Load-bearing roller      | Article no. |
|--------------------------|-------------|
| with scales on the right | 6-17-030    |
| with scales on the left  | 6-17-040    |

## Wear-resistant plate



| Wear-resistant plate          | Article no. |
|-------------------------------|-------------|
| for hopper body IMI curved    | 6-09-002    |
| for hopper body ST/LH         | 6-09-001    |
| for hopper body IMI straight  | 6-09-006    |
| <b>Rubber</b> for hopper body | 6-09-011    |



| Wear-resistant plate     | Article no. |
|--------------------------|-------------|
| for discharge tray IM/ST | 6-07-002    |
| for discharge tray IMI   | 6-07-102    |
| for discharge tray ST C  | 6-07-302    |
| for discharge tray LH    | 1-07-002    |



| Wear-resistant plate    | Article no. |
|-------------------------|-------------|
| for chute IM/ST L=1250  | 6-13-001    |
| for chute IMI/ST L=1450 | 6-13-111    |
| for chute LH L=1230     | 1-13-001    |
| for chute LH-N-L=1300   | 1-13-010    |

## Extension channel



| Extension channel                   | Article no. |
|-------------------------------------|-------------|
| 1 m Steel IM/IMI                    | 6-20-022    |
| 1 m Steel ST                        | 6-20-000    |
| 1 m plastic IMI/ST                  | 6-20-060    |
| Plastic channel inset for 60-20-060 | 6-20-050    |



| Extension channel    | Article no. |
|----------------------|-------------|
| 1 m aluminium IMI/ST | 6-20-100    |
| LH                   | 1-20-000    |
| 1 m aluminium LH     | 1-20-100    |
| 1 m plastic LH       | 1-20-060    |

## Rubber apron



| Rubber apron                    | Article no. |
|---------------------------------|-------------|
| Discharge tray IM/ST closed IMI | 6-07-011    |
| Hose clip for rubber apron IMI  | 66-22-360   |

# Spare parts for truck mixers

## Draw hook



| Draw hook             | Article no. |
|-----------------------|-------------|
| complete IMI          | 6-21-066    |
| complete ST           | 6-21-006    |
| complete LH           | 1-21-006    |
| <b>Tension spring</b> | 6-21-025    |

## Channel coating



| Channel coating | Article no. |
|-----------------|-------------|
| IMI             | 6-21-010    |
| ST              | 6-21-008    |
| LH              | 1-21-008    |

## Crank chute support



| Crank chute support  | Article no. |
|----------------------|-------------|
| IM/ST B = 30         | 6-16-000    |
| IMI B = 50           | 6-16-600    |
| LH B = 60            | 1-16-000    |
| <b>Rubber handle</b> | 6-21-017    |

## Four stage rotary switch




| Four stage rotary switch | Article no. |
|--------------------------|-------------|
| MB                       | 6-26-015    |
| MAN                      | 6-26-014    |
| MAN (Klöß-Mö)            | 6-26-051    |
| MAN K&N neu              | 6-26-052    |
| MB Actros KlöMö          | 6-26-050    |

## Spray nozzle



| Spray nozzle             | Article no. |
|--------------------------|-------------|
| R3/4"                    | 6-22-123    |
| Spray nozzle             | 6-22-121    |
| <b>Water hose 19 x 4</b> | 6-22-071    |

## Single gear rack transmitter




| Single gear rack transmitter | Article no. |
|------------------------------|-------------|
| Hub 70,0 MF                  | 6-25-058    |
| Hub 110 MF                   | 6-25-190    |

## Double gear rack transmitter



| Double gear rack transmitter | Article no. |
|------------------------------|-------------|
| MF 70/70 MF                  | 6-25-006    |
| 70/110 MF                    | 6-25-027    |
| 2 x Hub 70/110 MF            | 6-25-083    |

## Gear rack transmitter acces.




| Accessories                             | Article no. |
|-----------------------------------------|-------------|
| <b>Simple transmitter box</b>           |             |
| Driver's cab Hub 70 MF                  | 6-25-410    |
| Driver's cab<br><b>retainer bracket</b> | 6-25-280    |

## Accessories




| Accessories       | Article no. |
|-------------------|-------------|
| Fixed coupling GK | 6-22-252    |
| Hose joints       | 6-22-205    |

## Three way valve



| Three way valve        | Article no. |
|------------------------|-------------|
| Connecting nipple 1/2" | 6-22-300    |
| 1/2" LH                | 6-22-239    |

## Ball valve



| Ball valve        | Article no. |
|-------------------|-------------|
| 1 1/2" IG/IG      | 6-29-001    |
| 1" IG/IG          | 6-22-022    |
| 1/4" AG/IG „Mini“ | 6-22-238    |

## Remote control



| Remote control             | Article no. |
|----------------------------|-------------|
| L = 5.000 mm Hub 70 IMI/ST | 6-25-050    |
| L = 6.000 mm Hub 70 IMI/ST | 6-25-060    |
| L = 8.000 mm Hub 70 IMI/ST | 6-25-081    |
| Other lengths on request.  |             |



| Remote control            | Article no. |
|---------------------------|-------------|
| L = 5.000 mm Hub 110 LH   | 6-25-069    |
| L = 6.000 mm Hub 110 LH   | 6-25-067    |
| L = 8.000 mm Hub 110 LH   | 6-25-072    |
| Other lengths on request. |             |



| Remote control            | Article no. |
|---------------------------|-------------|
| FH 1.100 mm ZG coupling   | 6-25-401    |
| FH 1.620 mm pump/coupling | 6-25-403    |

## Ball valve



| Ball valve                    | Article no. |
|-------------------------------|-------------|
| 1 1/2" IG/IG rep.             | 6-29-021    |
| 1" IG/AG with drain 1/4" rep. | 6-29-022    |
| 3/4" IG/AG rep.               | 6-22-501    |

## Water meter



| Water meter                                    | Article no. |
|------------------------------------------------|-------------|
| 500 l                                          | 6-22-713    |
| 1.000 l                                        | 6-22-714    |
| <b>Screw connection<br/>for water meter 2"</b> | 6-22-712    |
| <b>Water hose 32 x 6</b>                       | 6-22-012    |

# Spare parts for truck mixers

Many more spare parts on request.  
Contact us!

## Threaded adapter




| Threaded adapter                                  | Article no. |
|---------------------------------------------------|-------------|
| top                                               | 6-04-207    |
| with shut-off valve below                         | 6-04-209    |
| <b>Water level control tube</b><br>20 x 1,5 L=625 | 6-04-212    |
| <b>Polypropylene ball 15 mm</b>                   | 6-04-222    |

## Water pump




| Water pump      | Article no. |
|-----------------|-------------|
| NA34R           | 6-22-530    |
| NST III         | 6-22-077    |
| Coupling sleeve | 6-22-009    |
| Clutch hub      | 6-22-010    |

## Temperature switch




| Temperature switch    | Article no. |
|-----------------------|-------------|
| 2 pin TB Sauer 60-55° | 6-47-060    |
| 2 pin 90°             | 6-47-070    |
| 2 pin LH              | 6-47-054    |
| 1 pin                 | 6-47-003    |

## ASA oil cooler



| Use of paper               | Article no. |
|----------------------------|-------------|
| ASA oil cooler             | 6-47-005    |
| ASA oil cooler long design | 6-47-035    |



| Fan                     | Article no. |
|-------------------------|-------------|
| ASA oil cooler ASA 24 V | 6-47-100    |
| ASA oil cooler AKG 24 V | 6-47-015    |

## Admixture container



| Admixture container                        | Article no. |
|--------------------------------------------|-------------|
| 30 L                                       | 6-40-000    |
| Draining admixture container               | 6-40-099    |
| Frame for admixture container              | 6-40-001    |
| <b>Rubber clamping</b><br>with hooks L=600 | 6-40-098    |

## Flow concrete channel




| Flow concrete channel | Article no. |
|-----------------------|-------------|
| Ø 200 mm LH           | 1-20-014    |
| Ø 200 mm ST           | 6-20-011    |
| Ø 200 mm IMI          | 6-20-300    |
| <b>Pipe clamp</b>     | 6-20-340    |



| Retaining jig            | Article no. |
|--------------------------|-------------|
| Mudguard IM/ST           | 6-20-035    |
| Support concrete channel | 6-20-040    |

## Pipe mounting



| Pipe mounting                                   | Article no. |
|-------------------------------------------------|-------------|
| Ø 200 mm H=190                                  | 6-20-013    |
| Ø 200 mm H=120                                  | 6-20-113    |
| <b>Rubber ring</b>                              | 6-20-017    |
| <b>Retaining pipe for attachment</b><br>Chassis | 6-20-085    |

☐ Inquire

☐ Order

### Your address

|        |                      |         |                      |
|--------|----------------------|---------|----------------------|
| Name   | <input type="text"/> | Company | <input type="text"/> |
| Street | <input type="text"/> | Place   | <input type="text"/> |
| E-Mail | <input type="text"/> | Phone   | <input type="text"/> |

| Description          | Article no.          | Amount               | Price Euro           |
|----------------------|----------------------|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |

### Date, Signature

### Comment

|                      |                      |
|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> |



### Intermix GmbH

Grüntensteinstraße 1 · D-87751 Heimertingen  
Tel. +49 (8335) 98 28-0  
Fax +49 (8335) 98 28-30  
info@intermix.de · www.intermix.de

We are happy to prepare an offer for you!

**Central Services Aichtal**

Putzmeister Concrete Pumps GmbH  
Max-Eyth-Straße 10 · 72631 Aichtal  
Tel. +49 (7127) 599-0 · Fax +49 (7127) 599-520  
pmw@pmw.de · www.putzmeister.de

**Putzmeister Service Center Berlin**

Putzmeister Concrete Pumps GmbH  
Kiesweg 4-5 · 16348 Wandlitz  
Tel. +49 (33397) 778-0 · Fax +49 (33397) 778-24  
Notfall +49 172 713 95 33  
nl-berlin@pmw.de · www.putzmeister.de

**Putzmeister Service Center Essen**

Putzmeister Concrete Pumps GmbH  
Im Teelbruch 89 · 45219 Essen - Kettwig  
Tel. +49 (2054) 9512-0 · Fax +49 (2054) 9512-14  
Notfall +49 173 307 83 62  
pmw@pmw.de · www.putzmeister.de

**Putzmeister Service Center Frankfurt**

Putzmeister Concrete Pumps GmbH  
Industriestraße 10 · 63584 Gründau Rothenbergen  
Tel. +49 (6051) 4805-800 · Fax +49 (6051) 4805-850  
pmw@pmw.de · www.putzmeister.de

**Branch Gera**

Putzmeister Concrete Pumps GmbH  
Wiesenring 15 · 07554 Korbußen  
Tel. +49 (36602) 324-0 (24-Stunden Service)  
Fax +49 (36602) 324-25  
nl-gera@pmw.de · www.putzmeister.de

**Putzmeister Service Center Hamburg**

Putzmeister Concrete Pumps GmbH  
Bei den Kämpfen 13 · 21220 Seevetal  
Tel. +49 (4185) 7938-0 · Fax +49 (4185) 3682  
Notfall +49 (4185) 7938-12  
nl-hamburg@pmw.de · www.putzmeister.de

**Putzmeister Service Center München**

Putzmeister Concrete Pumps GmbH  
Kirchhoffstraße 10 · 85386 Eching  
Tel. +49 (8165) 9599-0 · Fax +49 (8165) 9599-30  
Notfall +49 8165 9599-24  
nl-muenchen@pmw.de · www.putzmeister.de

**Intermix-Putzmeister Fahrmischer**

Grüntensteinstraße 1 · 87751 Heimertingen  
Tel. +49 (8335) 98 28-0 · Fax +49 (8331) 98 28-30  
info@intermix.de · www.intermix.de

